

POWER OVER ETHERNET (POE) GATEWAY REQUIREMENTS

DL-Windows can only configure Gateways when the Gateways are powered up and connected to the same subnet to which the DL-Windows computer is *also* connected.

Power Over Ethernet Gateways derive their power from their Ethernet (RJ-45) cable; therefore a "powered" Ethernet connection must be used when powering up and configuring POE Gateways.

If the subnet to which DL-Windows is connected is not a "powered" Ethernet connection, power can be supplied to the POE Gateways by a "Power Over Ethernet Injector" device (available at many electronic retail supply companies).